

1. GENERAL

This manual is used for the maintenance of FANUC AC Spindle Servo Units A06B-6044-H007 through H011 and their related options.

FANUC AC Spindle Servo Units provide smooth, noiseless, and reliable control of AC spindle motors by unique driving methods using a microprocessor. By using a regenerative braking system, the energy regenerated at the time of deceleration is returned to the power source for efficient saving of power.

1.1 Structure

The FANUC AC Spindle Servo Unit is composed of the following units and parts.

- (1) Spindle control unit
 - (Basic) { (1.1) Units
 - (1.2) Printed circuit board
 - (1.3) ROM
- (2) Fuses (Spare) (Basic)
- (3) Connectors (Basic)
- (4) D/A converter (Optional)
- (5) Power transformer (Optional)
- (6) Spindle orientation control circuits (Optional)




Fig. 1.1.1

1.2 Specification of main components of AC spindle servo unit


Table 1.2

Application motor or name	Specification drawing number	Unit drawing number	PCB drawing number	ROM		Specification drawing number of applicable AC spindle motor
				Specification drawing number	Classification	
Spindle servo unit for model 3	A06B-6044-H007	A06B-6044-C008	A20B-0009-0530	A06B-6044-C507#J10	J10	A06B-0704-B001, 2
Spindle servo unit for model 6	" H008	" C008	" 0531	" C508#J11	J11	A06B-0707-B001, 2
Spindle servo unit for model 8	" H009	" C009	" 0532	" C509	J02	A06B-0706-B001, 2
Spindle servo unit for model 12	" H010	" C010	" 0533	" C510	J03	A06B-0705-B001, 2
Spindle servo unit for model 15	" H011	" C011	" 0534	" C511	J04	A06B-0708-B001, 2
D/A converter (BCD)	A06B-6041-J031					
D/A converter (BINARY)	" J032					
Orientation circuits A	" J110		A20B-0008-0240			
Orientation circuits B	" J111		" 0241			
Orientation circuits B (2-level speed change)	" J120		" 0030			
Orientation circuits D (3-level speed change)	" J121		A20B-0009-0520			

(Note 1) The mounted parts (except ROMs) of printed circuit boards A20B-0009-0530 through 0534 are the same. Setting and adjustment of them are different.

(Note 2) The location of ROM is MD25. (See appendix I-7 PCB parts mounting diagram.)

(Note 3) The meanings of the codes printed on the ROMs are shown in the figure to the right.



1.3 Maintenance equipment

1.3.1 Equipment and tools used for adjustment

Table 1.3.1

Name	Specifications	Use
AC voltmeter	1V through 300V ($\pm 2\%$)	For measuring AC power supply voltage
Screwdriver	⊕ : large, and medium size ⊖ : large, medium, and small size	_____

1.3.2 Equipment and tools used for repairs

Table 1.3.2

Name	Specifications	Use
AC voltmeter	1V through 300V ($\pm 1\%$)	For measuring AC power supply voltage
DC voltmeter	1mV through 500V ($\pm 1\%$)	For confirmation of DC power supply voltage and offset voltage
Multimeter		For resistance check
Screwdriver	⊕ : large, and medium size ⊖ : large, medium, and small size	_____

1.4 Operation start procedure at installation

Confirm the following items sequentially at installation.

Table 1.4.1

Item	Contents	Remarks
1	Confirm whether the specifications of the motor, servo unit, and optional units are right.	Confirm that the correct unit, PCBs, and ROMs are used for the motor. (See Table 1.2)
2	Check for external damage.	Check that the power resistor or the parts on the PCB are not damaged.
3	Confirm the voltage, voltage regulation, power capacity (kVA), and frequency of the AC power source.	See Tables 2.1.1
4	Connect the ground lines, power lines, and signal lines.	See items, 2.1, 2.2, 2.3 and appendix 1-1.
5	Confirm the setting and adjustment.	See item 3.1.
6	Turn on the AC power, and confirm that the PIL lamp (green) on the PCB lights.	
7	Confirm that the motor rotates in both directions correctly in response to rotation commands.	
8	Confirm the motor operation for all speeds.	
9	Adjust the spindle orientation circuits.	See Chapter II.

2. CONNECTION

Confirm the connections referring to the connection diagram (Appendix 1-1, 1-2) and the cable layout (Appendix 1-3). See the cable specifications (Appendix 1-4) for details on cables.

2.1 Connection of power source

2.1.1 Confirmation of power voltage and capacity

Measure the AC power voltage before supplying AC power and take the necessary steps listed below according to the voltage.

Table 2.1.1-(1)

AC power voltage	Nominal voltage	Procedure
170V – 220V	200V	Set toggle switch SW in the 200V position.
210V – 242V	220V	Set toggle switch SW in the 220V position.
230V – 253V	230V	It is necessary to reduce the voltage to 200V using a transformer (autotransformer).
254V or more	380V – 550V	It is necessary to reduce the voltage to 200V using an insulation transformer.

The input power specifications of the AC spindle servo unit are listed in Table 2.1.1-(2). The power supply should be enough to avoid power drops even at maximum load.

Table 2.1.1-(2)

Nominal rating voltage		AC 200V/220V (changeable) 3-phase				
Allowable voltage regulation		-15% ~ +10%				
Frequency		50Hz/60Hz ± 1Hz (Unchangeable)				
Power capacity	Motor model	3	6	8	12	15
	Capacity at 30 min. rating	9KVA	12	17	22	26

2.1.2 Connection of the protecting ground line

Connect the ground line to ground terminal G before connecting the power cable. Use a wire that matches the breaker.

2.1.3 Connection of power source cable

Connect the power source cable after connecting the ground line. There is no conditions on phase rotation of the AC spindle servo unit.

2.2 Connection of AC spindle motor

Connect the AC spindle motor referring to the connection diagram (Appendix I-1).

If the power lines are not connected correctly, the motor vibrates and stops (Alarm No. 2).

2.3 Connection of signal lines

Connect the signal lines referring to the connection diagram (Appendix I-1).

If the optional spindle orientation control circuits are added, connect them referring to the connection diagram for each option (Chapter II, Appendix II-1).

3. SETTING AND ADJUSTMENT

3.1 Setting on the unit and PCB

See the mounting diagram (Appendix I-6, I-7) for the locations of parts to be set on the unit and PCB. Confirm the following items before turning on the power.

Table 3.1.1

No.	Item	Remarks
1	Setting of toggle switch SW for changing the voltage	See item 2.1.
2	Confirmation of setting terminals (short bars)	See Table 3.1.2.

Table 3.1.2

Terminal No.	Content	Setting	At shipment from FANUC	
S1	Machine ready signal [MRDY]	Used	OFF <input type="checkbox"/> ON <input checked="" type="checkbox"/>	ON
		Unused	ON <input type="checkbox"/> ON <input checked="" type="checkbox"/>	
S2	Analog override	Used	OFF <input type="checkbox"/> ON <input checked="" type="checkbox"/>	ON
		Unused	ON <input type="checkbox"/> ON <input checked="" type="checkbox"/>	
S3	Same as above	Used	ON <input type="checkbox"/> ON <input checked="" type="checkbox"/>	ON
		Unused	OFF <input type="checkbox"/> ON <input checked="" type="checkbox"/>	
S4	Velocity command signal	External analog voltage command	OFF <input type="checkbox"/> ON <input checked="" type="checkbox"/>	ON
		R01 through R12 commands	ON <input type="checkbox"/> ON <input checked="" type="checkbox"/>	
S5	Setting of velocity feedback amount corresponding to the rated command	4500 rpm	B: Short B <input type="checkbox"/> A <input checked="" type="checkbox"/>	Depends on motor
		6000 rpm	A: Short B <input type="checkbox"/> A <input checked="" type="checkbox"/>	
S6 ~ S7	Phase compensation for velocity control	Motor's model	3 6 8 12 15	Depends on motor
		S6	ON <input type="checkbox"/> ON <input checked="" type="checkbox"/> ON <input type="checkbox"/> ON <input checked="" type="checkbox"/>	
		S7	OFF <input type="checkbox"/> ON <input type="checkbox"/> ON <input checked="" type="checkbox"/>	

Since variable resistors RV1 through RV19 have been adjusted by FANUC at shipment, they need not be adjusted. The variable resistors listed in Table 3.1.3 can be readjusted if necessary. If variable resistors listed in Table 3.1.4 must be adjusted for offset or rotational speed, it should be done after turning on the power.

(1) The following potentiometer can be adjusted by the user.

Table 3.1.3

Variable resistor No.	Contents	Standard setting by FANUC at shipment	Adjustment procedure
RV3	Setting of speed arrival level	If the motor speed is 85% through 115% of the rated speed, the speed arrival signal is issued.	See the Appendix
RV4	Speed detection level	3% of the rated speed is detected.	
RV5	Torque limit value		

(2) The following potentiometer are used for sight adjustments of the rated speed and offset.

Table 3.1.4

Variable resistor No.	Contents	Adjustment procedure
RV1	Adjustment of velocity command voltage level	See Appendix I-9
RV2	Adjustment of velocity command voltage offset	
RV9	Slight adjustment of rated speed at forward rotation (SFR)	
RV11	Slight adjustment of rated speed at reverse rotation (SRV)	
RV13	Offset adjustment when a speed of zero is commanded.	

(Note 1) The other variable resistors have been adjusted by FANUC at shipment. Thus, they are not adjusted by the user.

Appendix I-9 gives a list of adjustments for the potentiometer.

3.2 Setting and adjustment of spindle orientation control circuits

The setting and adjustment of spindle orientation control circuits are described in Chapter II.

4. MAINTENANCE

Check and clean the AC spindle motor and the servo unit as described below every six months so that they are in the best operating conditions. Checks should be made as often as required to keep the unit clean.

4.1 AC spindle motor

When the air duct, cooling fan, or fan guard of the AC spindle motor is dirty, the radiating efficiency will drop. Thus, they should be cleaned using compressed air or a vacuum cleaner.

4.2 AC spindle servo unit

Since a cooling fan is mounted in the upper part of the servo unit, resistors or other parts which are near the cooling fan will become dirty. Clean them with a vacuum cleaner.

5. TROUBLESHOOTING

If trouble occurs, find out the cause using the following list in item 5.1.

Before troubleshooting, confirmation of AC power voltage and DC power voltage on the printed circuit board should be performed.

Table 5-(1)

Confirmation of AC power voltage	Measure it at input terminals R, S, T, and G. See 2.1		
Confirmation of DC power voltage	Voltage	Check terminal	Rated voltage
	+24V	Between +24 and 0V	Approx. 25V \pm 10%, Ripple: Approx. 0.5V
	+15V	Between +15 and 0V	+15V \pm 4% (Nonadjustable)
	+5V	Between +5 and 0V	+5V \pm 1% (Adjustment: RV15)
	-15V	Between -15 and 0V	-15V \pm 4% (Nonadjustable)

5.1 Classification of troubles

Table 5-(2)

Item	Type of trouble	Reference
1	Power ON indicating lamp PIL does not light.	Item 5.1.1
2	Alarm lamps on PCB are on.	Item 5.1.2
3	Number of motor rotations differ from the specified number.	Item 5.1.3
4	Motor does not operate.	Item 5.1.3
5	Vibration and noise during operation are abnormal.	Item 5.1.4
6	Noise is made during deceleration.	Item 5.1.5
7	Speed overshoots or hunting in motor	Item 5.1.6
8	Cutting power is too low.	Item 5.1.7
9	Spindle orientation is not performed correctly.	Item 5.1.8
10	Acceleration/deceleration is too long.	Item 5.1.9
11	DC power voltage on PCB is not correct.	Item 5.1.1

5.1.1 Power ON indicating lamp PIL does not light.

Table 5.1.1

Item	Cause of trouble	Check procedure	Countermeasure
1	AC power source is not supplied	Measure the voltage at power input terminals R, S, and T.	
2	Fuse F4 has blown.	Refer to Appendix I-6	Replace fuse F4 (5A).
3	Fuses AF1, AF2, and AF3 have blown.	Confirm whether the alarm indications of AF2 and AF3 have appeared. Refer to Appendix I-6.	Replace fuses AF1, AF2 and AF3. If the new fuses also below, the printed circuit board must be replaced.
4	Printed circuit board is not connected correctly to CN6 and CN7.	Confirm that a groove of the connector guide pin can be seen at the surface of the connector on PCB.	Insert the PCB correctly.
5	The power is not output to 19A and 19B due to problems in transformer TF.	Measure the voltage at the following terminals: <ul style="list-style-type: none"> • Between 19A and CT • Between 19B and CT If voltage of about 19V AC is output to 19A and 19B, the transformer is not defective.	Replace transformer TF.
6	Power circuit on PCB is defective.	The power to lamp PIL is supplied using +5V and -15V. Measure the voltage according to Table 5-(1).	Replace the PCB.

5.1.2 Alarm lamps on PCB are on.

Four LED alarm indicators are mounted on the PCB and they correspond to the values of hexadecimal number.




Fig. 5.1.2

The combinations of lighting alarm indicators indicate the alarm contents listed in Table 5.1.2.

No.	Alarm indication (○ : lighting)				Alarm contents
	8	4	2	1	
1				○	Motor is overheated. (Thermostat is not working.)
2			○		Speed deviation amount has exceeded allowable range.
3			○	○	Fuse F7 in DC link circuit has blown.
4		○			Fuse F1, F2, or F3 in AC link circuit has blown.
5		○		○	Fuse AF1, AF2, or AF3 on PCB has blown.
6		○	○		Motor speed has exceeded the maximum rated speed. (Analog mode detection: 13% TYP)
7		○	○	○	Motor speed has exceeded the maximum rated speed. (Digital mode detection: 11%)
8	○				Power supply voltage (+24V) is too high.
9	○			○	Radiators for power semiconductors have become overheated.
10	○		○		Voltage of +15V power source has dropped abnormally.
11	○		○	○	Voltage of DC link circuit is too high.
12	○	○			Overcurrent has flowed in the DC link circuit.
13	○	○		○	CPU alarm
14	○	○	○		ROMs are not mounted correctly.

(1) Alarm No. **1** Motor is overheated.

Table 5.1.2-(1)

Item	Cause of trouble	Check procedure	Countermeasure
1	Defective fan motor in the AC spindle motor		Replace the fan motor.
2	Overload operation	Check the load using a load meter.	Change the cutting conditions or cutting tool.
3	Contamination of the motor's cooling system		Clean around the cooling system using compressed air or a vacuum cleaner.
4	Defective wiring	Check the connection between the motor and servo unit.	

(2) Alarm No. [2] Speed deviation amount is too much.

Table 5.1.2-(2)



Item	Cause of trouble	Check procedure	Countermeasure
1	Overload	Check the load using a load meter.	Change the cutting conditions or cutting tool.
2	Malfunction of the torque limit circuit	Check the load using a load meter.	Replace the PCB.
3	Speed feedback signal is trouble.	Check the level of feedback signal	Adjust RV18, RV19.

(3) Alarm No. [3] Fuse F7 in the DC link circuit has blown.

If fuse F7 in the DC link circuit has blown, the power transistor module may be defective. The defective elements should be replaced according to the following procedures. If there is a possibility that the power transistor module was impaired due to PCB trouble, the PCB should also be replaced.

Please contact a FANUC service center if it is difficult to correct the trouble.

Table 5.1.2-(3)

Procedure	Contents
1	Turn off the AC power source (turn off the circuit breaker in the magnetic cabinet), and remove the power line of the motor.
2	<p>Measure the resistance values between the collector and emitter, and between the collector and base using multimeter (x10 ohm range).</p> <div style="display: flex; justify-content: space-around; align-items: center;"> <div style="text-align: center;">  <p>Transistor module terminals</p> </div> <div style="text-align: center;">  </div> </div> <p style="text-align: center;"> Normal: Several hundred ohms Defective: 0 through 10 ohms </p>
3	Replace the defective parts. Silicon grease should be used.
4	After replacement, measure the resistance values again listed in procedure 2.
5	Replace the printed circuit board if necessary.
6	Connect the motor power line, replace fuse F7, and start the operation again.

(4) Alarm No. [4] Fuse F1, F2, or F3 in the AC link circuit has blown.

Table 5.1.2-(4)

Item	Cause of trouble	Check procedure	Countermeasures
1	AC power impedance is too high. ex. When 2 transformers, are connected serially or autotransformer is connected.	<ul style="list-style-type: none"> Alarm lamp No. 4 goes on only during deceleration. Alarm lamp No. 4 goes on through fuse F1, F2, or F3 has not blown. 	Change the power source into low impedance power source. Looseness of connection. ex. Looseness of connection or loss of phase
2	Power transistor module is defective.	See alarm No. 3.	See alarm No. 3. Replace the power transistor module and fuse.
3	Diode module or thyristor module is defective.	Remove the connecting lines of diode modules DM1 through 3 and thyristor modules SM1 through 3, and check the resistance value between terminals A and K using a multimeter. If they are defective, 0 ohm will be measured.	Replace the defective parts and fuses.
4	Surge absorber or capacitor is defective.	Check surge absorbers Z1 through 3 and capacitors C4 through 6.	Replace the defective parts and fuses.

(5) Alarm No. [5] Fuse AF1, AF2, or AF3 on PCB has blown.

Table 5.1.2-(5)

Item	Cause of trouble	Check procedure	Countermeasures
1	PCB is defective.	Check the AC input voltage. See item 5.1.1-5.	Replace the PCB.
2	Power source voltage is abnormal.		

(6) Alarm No. [6] Overspeed (Analog detection)

Table 5.1.2-(6)

Item	Cause of trouble	Check procedure	Countermeasures
1	Setting and adjustment on PCB are not correct.	Confirm the setting and adjustment on the PCB.	Change S5.
2	Specification of ROM is different.	Check the specification referring to Table 1.2.	Replace the ROM.
3	PCB is defective.		Replace the PCB.

(7) Alarm No. [7] Overspeed (Digital detection)
Same as the above.

(8) Alarm No. **8** Overvoltage of +24V input

Table 5.1.2-(7)

Item	Cause of trouble	Check procedure	Countermeasure
1	AC power voltage has exceeded 110% of the rated voltage.	Check the power source voltage.	
2	Toggle switch for changing the voltage level is set in an incorrect position.	Check the power source voltage.	Set the toggle switch in the correct position. 200V → 220V

(9) Alarm No. **9** Radiator overheating

Table 5.1.2-(8)

Item	Cause of trouble	Check procedure	Countermeasure
1	Cooling fan is defective.	Check whether the cooling fan is operating.	Replace the cooling fan.
2	Overload operation	Check the load using a load meter.	Change the cutting conditions.
3	Contamination of radiator		Clean the radiator using compressed air or a vacuum cleaner.

(10) Alarm No. **10** Undervoltage of +15V input

This alarm indicates that the AC power voltage has dropped abnormally (-15% or less).

(11) Alarm No. **11** Overvoltage of DC link circuit

Table 5.1.2-(9)

Item	Cause of trouble	Check procedure	Countermeasure
1	Fuses F5 or F6 has blown.	Check fuses F5 and F6 using a multimeter. If the fuses have blown the transistor modules should be checked in the same manner as described in alarm No. 3	Replace the fuse.
2	Power source impedance is too high.		Change the specification of the AC power source.
3	PCB is defective.		Replace the PCB.

(12) Alarm No. **12** Overcurrent of DC link circuit

Table 5.1.2-(10)

Item	Cause of trouble	Check procedure	Countermeasure
1	Output terminal or motor winding is shorted.	Check the connection.	
2	Power transistor module is defective.	If this alarm occurs again immediately after resetting, the transistor modules should be checked in the same manner as described in alarm No. 3.	Replace the defective parts.
3	PCB is defective.		Replace the PCB.

(13) Alarm No. **13** CPU alarm
Replace the PCB.

(14) Alarm No. **14** Mounted ROM is not correct.
Mount the ROM chip whose specification is correct. Be sure to verify that the chip is mounted.
(See Table 1.2)

5.1.3 Motor does not operate or the revolution speed differ from the specification.

Table 5.1.3

Item	Cause of trouble	Check procedure	Countermeasure
1	Trouble analysis	Alarm lamp on the PCB of the spindle servo unit lights when a rotational command is issued.	Refer to item 5.1.2.
		The alarm lamp does not light.	Refer to the following item No. 3.
2	Command signal line is connected incorrectly.	Check the connection of the signal line.	
3	PCB is defective.		Replace the PCB.

5.1.4 Vibration and noise during operation are abnormal.

Table 5.1.4

Item	Cause of trouble	Check procedure	Countermeasure
1	Motor is defective.		Replace or repair the motor.
2	PCB is defective.		Replace the PCB.

5.1.5 Noise during deceleration

Since the regenerated energy is returned to the power source through the regenerative circuits during deceleration, the regenerated energy limitation circuit is activated if the energy returned is too much. This may cause the motor to make noise due to the change in the motor current waveform. In this case, the noise can be reduced by turning potentiometer RV6 counterclockwise (Standard setting: 30%). However, the period required for deceleration becomes longer as the RV6 is turned counterclockwise.

5.1.6 Speed overshoots, hunting in motor

Table 5.1.6

Item	Cause of trouble	Check procedure	Countermeasure
1	Setting and adjustment on PCB are incorrect.	Turn potentiometer RV12 clockwise to increase the gain. (Standard setting: 50%)	Change the setting.
2	Hunting in spindle	Decrease the gain (Turn potentiometer RV12 counterclockwise)	Readjustment

5.1.7 Cutting power is too low.

Table 5.1.7

Item	Cause of trouble	Check procedure	Countermeasure
1	Specification of ROM is different.	Confirm the specification referring to Table 1.2	Replace the ROM chip with the proper one.
2	Torque limitation command is applied.	Confirm the signal line.	
3	Looseness of belt	Confirm the tension of belt	

5.1.8 Spindle orientation is not performed correctly.

Table 5.1.8

Item	Cause of trouble	Check procedure	Countermeasure
1	Setting and adjustment in the spindle orientation control circuits are incorrect.	Check whether the setting and adjustment conform to the data sheet.	See Chapter 11 – Setting and adjustment in the spindle orientation control circuits.
2	PCB of the spindle orientation control is defective.		Replace the PCB.
3	Setting on the spindle control PCB is adjusted incorrectly.		Adjust the setting on the PCB.

5.1.9 Acceleration/deceleration time is too long.

Table 5.1.9

Item	Cause of trouble	Check procedure	Countermeasure
1	Torque limitation command is applied.	Confirm the signal line.	
2	Specification of ROM is different.	Confirm the specification referring to Table 1.2.	Replace the ROM chip with the proper one.
3	Setting on the PCB is adjusted incorrectly.	If the set value of potentiometer RV6 is too small, the time required for deceleration becomes longer. (See item 5.1.5.)	Readjust the RV6.

6. REPLACING PRINTED CIRCUIT BOARD AND FUSE

6.1 Replacing fuses

To replace fuses F1 through F7 which are in the unit, it is necessary to open the cover of the unit. The following figure shows how to open the cover.






Fig. 6.1.1

6.2 Replacing printed circuit boards


(1) Removal

Table 6.2.1

Procedure	Contents
1	Turn off the power and remove the cables connected to the PCB. Note the correspondence between cables and connectors.
2	Remove the six screws fixing the PCB. 
3	Slowly pull the right side of the PCB until connectors CN4 through CN6 are disconnected (pins are inserted from the back side) and remove the PCB. 

(2) Mounting


Table 6.2.2

Procedure	Contents
1	<p data-bbox="480 499 1331 589">Insert connectors CN4 through CN7 to the corresponding connectors on the unit fitting the guide holes to the guide pins until the grooves on the guide pins (see the figure below) can be seen at the surface of the connector on the PCB.</p>  <p data-bbox="596 981 687 1003">Guide pin</p> <p data-bbox="874 1025 1078 1070">Groove for confirming correct insertion</p>
2	Fix the PCB to the unit and tighten the six screws. See (1)-2 above.
3	Connect the cables to the connectors.
4	Check the specification of ROM and the setting on the PCB, and start the operation.

6.3 Replacing the spindle orientation control circuits

(1) Removal


Table 6.3.1

Procedure	Contents
1	Remove the PCB in the spindle control unit as described in item 6.2.(1). Remove the flat cables connecting between PCBs.
2	Remove the four screws fixing the stays of the PCB for the spindle orientation control circuits. 


(2) Mounting

Mount the PCBs by reversing the procedures mentioned above.

Appendix I-1 Connection diagram





Appendix I-2 Detailed connections




Appendix I-3 Cable layout

(1) For Models 3, 6




(2) For Models 8, 12

Connection diagram for power and signal lines







(3) For Model 15



Appendix I-4 Cable specifications





The cable specifications are as shown below.
Prepare cables by users.

(1) Power line and motive power line for respective motor models

Use	Symbol	Specifications	Remarks
For model 3 (Lower than 12 KVA)	K1 K2	<p>Cabtyre cable JIS C 3312, 4 conductors</p>  <p>70/0.32 (5.5mm²)</p> <p>16.5 φ</p> <p>Crimp style terminals T5.5-6</p> <p>Crimp terminals T5.5-6</p>	A02B-0008-K853 7m long
For model 6 (Lower than 16 KVA)	K1 K2	<p>Cabtyre cable JIS C 3312, 4 conductors</p>  <p>50/0.45 (8mm²)</p> <p>20 φ</p> <p>Crimp style terminals T8-6</p> <p>Crimp terminals T8-6</p>	A02B-0008-K854 7m long
For model 8, 12 (Lower than 25 KVA)	K1 K2	<p>Cabtyre cable JIS C 3312, 4 conductors</p>  <p>88/0.45 (14mm²)</p> <p>24 φ</p> <p>Crimp style terminals T14-6</p> <p>Crimp terminals T14-6</p>	A02B-0008-K855 7m long
For model 15 (Lower than 30 KVA)	K1 K2	<p>Cabtyre cable JIS C 3312, 1 conductor x 4 pcs.</p>  <p>7/20/0.45 (22mm²)</p> <p>14.5 φ</p> <p>Crimp style terminals T22-8</p> <p>Crimp terminals T22-8</p>	A14mm ² cable is employable, if model 15 is not continuously operated with a heavy load of exceeding 25 KVA.


(2) Common line

The following cables are common to each model.


Use	Symbol	Specifications	Remarks
Spindle servo unit AC spindle motor (Cooling fan)	K3	<p>Vinyl cabtyre cable JIS C 3312, 2 conductors</p>  <p>Crimp style terminals T2-5</p> <p>37/0.26 (2mm²)</p> <p>10.5 φ</p> <p>Crimp style terminals T2-5</p>	A660-8001-T865 /L7R03 7m long
Spindle servo unit AC spindle motor (for signal)	K4	<p>Spindle servo unit option connector</p> <p>Attached connector of spindle motor</p>  <p>Less than 10 φ</p> <p>0.3 mm²</p> <p>Shielded 4-paired cable</p> <p>MR-20 LFH made by Honda Tsushin Co.</p> <p>PVC sheath shield braided conductor</p> <p>Housing 350720-1 Contact 350689-1</p>	Cable only A66L-0001-0139 /L10R03 10m long
Spindle servo unit Power magnetic control (for signal)	K5	<p>Spindle servo unit connector (basic)</p> <p>Power magnetic control</p>  <p>12.5 φ</p> <p>CN1</p> <p>MR-50 LFH made by Honda Tsushin Co.</p> <p>Braided shield vinyl cable 50 conductors × 0.2mm² (7/0.18) made by Sanyo Denko</p>	Cable only A66L-0001-0042 /L10R03 10m long
Spindle servo unit Power magnetic control (for signal)	K6	<p>Spindle servo unit connector (basic)</p>  <p>10 φ</p> <p>CN3</p> <p>MR-20 LMH made by Honda Tsushin Co.</p> <p>Shielded 4-paired cable 0.3 mm²</p>	Cable only A66L-0001-0139 /L7R03 7m long

Appendix I-6 Unit parts mounting diagram


(1) Unit for Models 3 and 6 (A06B-6044-C008)



(2) Unit for Models 8 and 12 (A06B-6044-C009, C010)




(3) Unit for Model 15 (A06B-6044-C011)



Appendix I-7 PCB parts mounting diagram

- Notes
- ⊙ Check Terminal (CH 1 to 32, etc.)
 - ⓐ Potentiometer (RV1 to 19)
 - ▭ Terminal for setting (S1 to 7)



Appendix I-8 Main parts list

(1) Fuses and surge absorbers

Item	Symbol	Name	Specification				
			Model 3	Model 6	Model 8	Model 12	Model 15
1	F1 ~ 3	Fuse	A60L-0001-0127/25FH75		A60L-0001-0145		A60L-0001-0149
2	F4	Fuse		A60L-0001-0031/5A			
3	F5, 6	Fuse	A60L-0001-0036/PC1-20		A60L-0001-0036/PC1-30		
4	F7	Fuse	A60L-0001-0147		A60L-0001-0145		A60L-0001-0149
5	Z1 ~ 4	Surge absorber		A50L-0221-0062/441-12			
6	AF1	Fuse on PCB		A60L-0001-0046/3.2 (3.2A)			
7	AF2, 3	"		A60L-0001-0075/3.2 (3.2AS)			

(2) Main parts

Item	Symbol	Name	Specification				
			Model 3	Model 6	Model 8	Model 12	Model 15
1	P.C.B.	Printed circuit board	A20B-0009-0530	A20B-0009-0531	A20B-0009-0532	A20B-0009-0533	A20B-0009-0534
2	ROM	Memory element	J10	J11	J02	J03	J04
3	TM1 ~ 11	Transistor module			A50L-0001-0096		
4	SM1 ~ 3	SCR module	A50L-5000-0029/30			A50L-5000-0029/50	
5	DM1 ~ 3	Diode module	A50L-2001-0138			A50L-2001-0146	
6	D1 ~ 3	Diode			A50L-2001-0103/12JH11		
7	D4 ~ 6	Diode			A50L-2001-0103/12JG11		
8	D7	Diode			A50L-2001-0081/60		
9	D8	Diode			A50L-2001-0097/U06G		
10	C1 ~ 3	Capacitor			A421-0001-0103		
11	MCC	Electromagnetic contactor	A58L-0001-0094/200V1A1B		A58L-0001-0092/A		
12	TF	Transformer			A80L-0001-0276		
13	FAN	Cooling fan			A90L-0001-0099/A		
14	TH	Thermostat			A57L-0001-0028		
15	SW	Switch			A57L-0001-0030/2		

Appendix I-9 Adjustment of potentiometers on PCB

Notes 1. This table is applicable to PCBs of versions

A20B-0009-0530 to 0534.


2. Since the potentiometers, RV7, 8, 14 through 19, are adjusted by FANUC at shipment, they must not be readjusted by the user.

No.	Symbol	Item	Standard setting	Check terminals	Procedure
1	RV1	Velocity command voltage level		CH13-0V	See Subsection (1) on the next page.
2	RV2	Velocity command voltage offset		CH13-0V	See Subsection (1) on the next page.
3	RV3	Speed arrival detection level		CH10-0V	See subsection (4)
4	RV4	Speed detection level		CH9-0V	See subsection (5)
5	RV5	Torque limitation level			See subsection (6)
6	RV6	Regenerated power limitation	3 scale		See item 5.1.5.
7	RV7	VF conversion level (1)		CH23-0V	When the voltage between LM and 0M is 10V, the frequency is 200 ± 2 kHz.
8	RV8	Setting for speed detection circuit		CH18-0V	When the voltage between CH17 and 0V is 0.2V, 2.2 ± 0.1 V.
9	RV9	Adjustment of forward motor speed		Number of motor revolutions	See Subsection (2) on the next page.
10	RV10	Speed detection offset		CH17-0V	When the spindle is stopped, the offset voltage must be within ± 2 mV.
11	RV11	Adjustment of reverse motor speed		Number of motor revolutions	See Subsection (2) on the next page.
12	RV12	Velocity loop gain	5 scale		
13	RV13	Velocity loop offset		Spindle	See Subsection (3) on the next page.
14	RV14	Adjustment of loadmeter amplitude		LM-0M	10 ± 0.1 V at acceleration (without torque limit)
15	RV15	Voltage adjustment of +5V		+5V-0V	5 ± 0.05 V
16	RV16	Regenerated voltage limitation level	4 scale		
17	RV17	VF conversion level (2)		CH32-0V	When input voltage is 200V AC, the frequency is 24 ± 0.2 kHz.
18	RV18	Adjustment of RA offset		CH5-0V	2.5 ± 0.05 V in the state that CN2 is open.
19	RV19	Adjustment of RB offset		CH6-0V	Same as the above.

(1) Velocity command voltage (RV1, RV2)

When the velocity command voltage is 10V, the motor rotates at the rated speed.

Item	Measuring terminals	Adjustment procedure
Offset	CH13-0V	Set the motor in operating status and supply a velocity command voltage of 0V (equivalent to S00) to the motor. Adjust RV2 so that the voltage between the measuring terminals will not change when forward rotation and reverse rotation commands are issued alternately. See the following NOTE.
Level	CH13-0V	Next, supply a rated rotational command voltage of 10V to the motor, and adjust RV1 so that the voltage between the measuring terminals becomes $+10V \pm 0.05V$ when the spindle forward rotation command is issued.




(NOTE) For example, if the voltage at CH13 is $+5.0mV$ when the spindle rotates forward and it is $+5.0mV \pm 1.0mV$ when the spindle rotates in reverse, the offset error of the velocity command voltage is $\pm 1.0mV$.

(2) Rotational speed adjustment (RV9, RV11)

The number of motor revolutions can be adjusted accurately by the following procedure. At this time, the number of motor revolutions should be measured directly using a stroboscope or tachometer.

Item	Measuring point	Adjusting procedure
Number of forward motor revolutions	Spindle	Supply the rated velocity command voltage to the motor. Adjust RV9 so that the motor rotates at the rated speed when a forward rotation (SFR) command is issued.
Number of reverse motor revolutions	Spindle	Adjust RV11 so that the motor rotates at the rated speed when a reverse rotation (SRV) command is issued.

(NOTE) The forward rotation means that the AC spindle motor rotates counterclockwise (forward rotation) as seen from the shaft. Thus, it may not correspond to the forward rotation of the machine spindle.





(3) Velocity offset (RV13)

This adjustment is made so that the spindle will not rotate at low speed when a velocity command voltage of 0V is supplied. This should be performed after the previous adjustments.

Item	Measuring point	Adjusting procedure
Velocity offset	Spindle (or Motor)	Supply a velocity command voltage of 0V. Adjust RV13 so that the spindle will not rotate when forward or reverse rotation commands are issued.

(4) Speed arrival detection level (RV3)


Setting of the speed arrival detection level can be performed by using the following graph.



How to read the scale of potentiometer


(5) Speed detecting level (RV4)

Vertical axis is the percentage of motor speed when rated value is assumed as 100%. This signal can be used for confirmation when clutch or gear is being changed.





(6) Torque limit level (RV5)

Vertical axis is the percentage of torque when 30 minutes rated torque is assumed as 100%.



Appendix I-10 Description of check terminals

Terminal name	Signal name	Contents	Remarks								
CH1	DA2	Analog command voltage	0 ~ 10.0V								
CH2	DA1	Output voltage from D/A converter	0 ~ 10.0V								
CH3	PA	Phase A output from pulse generator	(2.5V ± 5%) ± 0.2V _{TYP.}								
CH4	PB	Phase B output from pulse generator	PA leads PB by 90° when CW rotation								
CH5	RA	Reference voltage of phase A	Direct current of PA: ±25 mV								
CH6	RB	Reference voltage of phase B	Direct current of PB: ±25 mV								
CH7	PSA	Phase A square wave	Duty 50% (at constant speed) ±10%								
0V	0V	0V of printed circuit board									
CH8	PSB	Phase B square wave	Duty 50% (at constant speed) ±10%								
CH9	SDTRF	Speed detection level	Variable 0.14V through 7.4V by RV4								
CH10	SARRF	Speed arrival level	Variable by RV3								
CH11	BUZY	Acceleration/deceleration busy	 1: During Acc/Dcc								
CH13	VCMD	Velocity command voltage	0 ~ ±10.0V⊕; CCW, ⊖CW								
CH14	RVP	Reverse rotation speed pulse	Pulse width: 3.2 microseconds (Only for reverse rotation)								
CH15	FWP	Forward rotation speed pulse	Pulse width: 3.2 microseconds (Only for forward rotation)								
CH16	0V	0V of printed circuit board									
CH17	TS1	F/V output of velocity feedback	6000 rpm (CCW): -10V								
CH18	TS2	Low speed detection signal	120 rpm (CCW): -2.2V								
CH20	TSA	Velocity feedback signal	Rated rotational speed: ±10V, CCW: ⊖								
CH21	LTRF	Output torque limitation voltage	Output = -[(V _{CH21} + 1.8)/10] X Maximum output								
CH22	CRU	Phase U current detection signal	Current per 1V <table border="1" data-bbox="933 1377 1252 1467"> <tr> <td>M3, 6</td> <td>M8</td> <td>M12</td> <td>M15</td> </tr> <tr> <td>16.7A</td> <td>25A</td> <td>35.7A</td> <td>50A</td> </tr> </table>	M3, 6	M8	M12	M15	16.7A	25A	35.7A	50A
M3, 6	M8	M12	M15								
16.7A	25A	35.7A	50A								
CH23	ERP	VF conversion output	CH28 10V: 20 kHz, width; 0.4 μs								
CH24	CRV	Phase V current detection signal	V phase motor current detection signal								
CH25	TRWF	Triangle wave signal	 10Vp-p								
CH26	CRW	Phase W current detection signal	W phase motor current detection signal								
CLK	CLK	Clock signal	312.5 kHz 200 ns typ								
+24	24V	Power source voltage of +24V	DC 25.6 V _{typ} , Ripple: 0.5V _{p-p} 100 Hz								
+15	15V	Power source voltage of +15V	-15V ± 4%								
+5	5V	Power source voltage of +5V	+5V ± 1% (Preadjusted by RV15)								
0V	0V	0V of printed circuit board	0V, same as CH16								
-15	-15V	Power source voltage of -15V	-15V ± 4%								

APPENDIX

- I-1 Connection diagram
- I-2 Detailed connections
- I-3 Cable layout
- I-4 Cable specifications
- I-5 Main circuit diagram
- I-6 Unit parts mounting diagram
- I-7 PCB parts mounting diagram
- I-8 Main parts list
- I-9 Adjustment of potentiometers on PCB
- I-10 Description of check terminals

II. SPINDLE ORIENTATION CONTROL CIRCUITS

Revision Record

FANUC AC SPINDLE SERVO UNIT MAINTENANCE MANUAL (B-53425E)


Edi- tion	Date	Contents	Edi- tion	Date	Contents
02	'81.10	correction of error.			
01	'81.9				

Terminal name	Signal name	Contents	Remarks
CH28	ER	Error voltage	0 – 10V
CH29	UCM	Phase U command voltage	
CH30	VCM	Phase V command voltage	
CH31	WCM	Phase W command voltage	
CH32	24VP		
19A	19A	Input voltage of 19V AC	
CT	CT	0V	
19B	19B	Input voltage of 19V AC	

1. GENERAL

1.1 Structure


1.1.1 Position coder (Stop position internal setting)




(Note 1) When a position coder is attached to lathe, etc., it can be used for this purpose.

(Note 2) The broken line marked with * is the cable route when the position coder attached to lathe or the position coder for the synchronous feed for machining center is used concurrently.

1.1.2 Position coder (Stop position external setting)



1.1.3 Magnetic sensor




2. ADJUSTMENT OF MAGNETIC SENSOR SYSTEM SPINDLE ORIENTATION

2.1 Mounting magnetizing element and magnetic sensor

Determine the mounting direction for the magnetizing element and magnetic sensor as follows. Incorrect mounting may cause repeating of clockwise and counterclockwise rotation of spindle without stopping during positioning, hunting, and the end of the magnetizing element and sensor head to stop in the opposite position.

Mounting magnetizing element and sensor

Item	Explanation
1	Mount the magnetizing element so that the reference hole moves and faces as shown in Figure 1 when the spindle rotates in the positive direction by the command of spindle motor CW rotation (SFR and VCMD positive).
2	Mount the magnetic sensor head so that the pin hole of the flange and the reference hole of the magnetizing element face in opposite directions.
3	The gap between the magnetizing element and sensor head should be a minimum of 1.5 ± 0.5 mm.
4	 <p style="text-align: center;">· Figure 1 Mounting magnetizing element</p>

2.2 Setting and adjustment of two speed steps type

Spindle orientation circuit C A06B-6041-J120
 Orientation circuit C PCB A20B-0008-0030

2.2.1 Setting and function of jumper terminal (SH)

The connection and function of jumper terminals (SH) which can be freely selected, are listed below. SH01 should be connected after the power is on since it is used only for adjustment and testing. It should be disconnected after adjustment making sure that LED7 goes off.

Connection and functions of jumper terminals (SH)
 (A double outline indicates the standard setting)

SH	(Note 1) Status		Function	Remarks
	1-2	2-3		
01	<input checked="" type="checkbox"/>	<input type="checkbox"/>	Test mode (Note 2)	Connected only for adjustment.
02	<input type="checkbox"/>	<input checked="" type="checkbox"/>	When an orientation instruction is issued after power is turned on and before driving the spindle, the motor shaft end rotates in a clockwise direction.	The setting on SH03 takes priority of the setting on SH02. The setting on SH02 is effected only when SH03 1-2 is connected.
	<input checked="" type="checkbox"/>	<input type="checkbox"/>	When an orientation instruction is issued after power is turned on and before driving the spindle, the motor shaft end rotates in a counterclockwise direction.	
03	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	Moves in the direction the spindle was turning just before the orientation instruction was issued.	The setting on SH02 becomes effective.
	<input checked="" type="checkbox"/>	<input type="checkbox"/>	The orientation direction is always CCW.	
	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	The orientation direction is always CW.	
04	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	Initial orientation speed is about $60 \times$ [spindle position loop gain s^{-1}] r.p.m. of the spindle. (usual rate)	Since spindle position loop gain is generally close to 5 sec.^{-1} , the usual rate is about 300 r.p.m.
	<input type="checkbox"/>	<input checked="" type="checkbox"/>	The initial rate of speed is limited to 1/3 the usual rate.	
	<input checked="" type="checkbox"/>	<input type="checkbox"/>	The initial rate of speed is limited to 2/3 the usual rate.	

Notes: (1) indicates connected, indicates not connected.

(2) When in Test Mode

(a) The orientation instruction is issued.

(b) Orientation end signal (ORAR 1,2) is not transferred.

(c) The spindle turns at the initial speed while SW1 (INITIALIZING BUTTON) is pressed. When it is released, the spindle stops at a fixed position.

(d) The red light emitting diode (LED 7) is on in this mode.

2.2.2 LED indicators

Seven display lamps (LED 1 - 7), indicating the meanings listed below, are mounted on this option board. (LED 1 and LED 2 are not mounted on board 01A.)

LED indicators

LED	Meaning	Color	Explanation
1	ORIENTATION	Green	Lights during execution of an orientation instruction. (ORCM 1 and 2 are connected: ON)
2	CLUTCH (gear) LOW	Green	Lights when the clutch (gear) LOW signal is on. (*CTH 1 and 2 are connected: ON)
3	MS PEAK LEVEL	Green	Lights while the peak value of the magnetic flux detection signal (MS) is out of the range of $\pm 10V$. Adjustment indicator.
4	SLOWDOWN PERIOD	Green	Lights during the low turning speed period when the spindle position approaches the stop position during orientation.
5	IN-POSITION FINE	Green	Lights when the value of MS output approaches within $+0.1^\circ$ of the spindle angle. Sometimes lights when the sensor is not on the magnetizing element.
6	IN-POSITION	Green	Lights when orientation has been completed and the spindle is within $\pm 1^\circ$ of the adjustment position. When it lights while not in TEST MODE, the Orientation Completion signal is transmitted. (ORAR 1 and 2 are connected: ON)
7	TEST MODE	Red	Lights when SH01 pins are connected. In this mode, the Adjustment Completion signal is not transmitted and ORCM is on. The orientation motion can be repeatedly confirmed by pressing SW1.

2.2.3 Potentiometer (POT) setting

Set the POT according to the following values followed by table before adjustment. * will be reset at a later stage.

Potentiometer settings

POT name	RV	1*	2*	3	4	5	6*	7*	8	9	11*
POT scale position		5.0	6.0	①	①	②	2.0	5.0	③	2	5.0

① RV3 and RV4 settings

Set RV3 and RV4 according to the distance H between the turning axis of magnetizing element and the center of the sensor head.

H (mm)	60 ~ 65	~70	~75	~80	~85	~90	~95	~100	~110
Scale position	7.0	6.0	5.0	4.0	3.0	2.5	2.0	1.5	0.5

② RV5 setting


Set RV5 according to the number of revolutions (N_{HM}) when the spindle rotates at rated speed.

N_{HM} (rpm)	2,000 ~ 2,200	~2,500	~2,700	~3,100	~3,500	~4,000	~4,500	~5,000	~6,000
Scale position	7.5	6.5	5.5	4.5	3.5	2.5	2.0	1.5	0.5

③ RV8 setting

Set RV8 according to the transmission ratio of $R_{H/L}$ of spindle HIGH/LOW.

$R_{H/L}$	~2.0	~2.2	~2.5	~2.8	~3.2	~3.7	~4.4	~5.3	~7.0
Scale position	2.0	3.0	4.0	5.0	6.0	7.0	8.0	9.0	10



Scale of potentiometer

2.2.4 Potentiometer adjustment

Adjust RV1 ~ RV11 according to the following table. Adjustment of orientation PCB must be performed after the adjustment of spindle control PCB. Orientation position may be shifted if the adjustment of RV12 or RV13 on spindle control PCB is altered.


Potentiometer adjustment

The following adjustments should be performed in Test Mode by connecting SH01 pins.

Term	POT name	Adjustment purpose	Condition	Adjustment method (Specification)
1	RV1	TS OFFSET	The spindle should be stopped.	Voltage across check 15 (TSA2) and 16 (OV) should be within ± 1.0 mV.
2	RV2	MS PEAK LEVEL	Keep pressing SW1 (INITIALIZING BUTTON)	Adjusted position until LED3 (MS PEAK LEVEL) begins to light.
3	RV3	SLOWDOWN REFERENCE		According to the setting terms.
4	RV4	AMS PEAK LEVEL		According to the setting terms.
5	RV5	SLOWDOWN TIME IN HIGH MODE	Clutch (gear) is HIGH. Press SW1 to stop the spindle at the fixed position. The *CTH signal is off (open).	Just before stopping LED4 (SLOW DOWN PERIOD) * should immediately light up clearly.
6	RV6	GAIN [H]	Clutch (gear) is HIGH. Press SW1 to stop the spindle at the fixed position. The *CTH signal is off (open).	Turn in the CW direction being careful not overshoot when stopping.
7	RV8	IN-POSITION	Clutch (gear) is HIGH. Press SW1 to stop the spindle at the fixed position. The *CTH signal is off (open).	LED5 (IN-POS. FINE) should light while LED 6 (IN-POSITION) is on.
8	RV8	SLOWDOWN TIME IN LOW MODE	Clutch (gear) is LOW. Press SW1 to stop the spindle at the fixed position. The *CTH signal is on (closed).	LED4 (SLOWDOWN PERIOD) should immediately light up clearly just before stopping. (See term 5)
9	RV9	GAIN [L]	Clutch (gear) is LOW. Press SW1 to stop the spindle at the fixed position. The *CTH signal is on (closed).	Turn in the CW direction being careful not to overshoot when stopping.
10	RV10	IN-POSITION [L]	Clutch (gear) is LOW. Press SW1 to stop the spindle at the fixed position. The *CTH signal is on (closed).	LED 5 (IN-POS. FINE) should be on when LED 6 (IN-POSITION) is on.

Term	POT name	Adjustment purpose	Condition	Adjustment method (Specification)
11	RV11	POSITION SHIFT		The stop position can be finely adjusted to within $\pm 1^\circ$ of the spindle angle.

After adjustment, release Test Mode making sure that LED 7 (Red) is off.



Parts mounting diagram
 Location of check terminals and potentiometers.

2.3 Setting and adjustment of three speed steps type

Orientation circuit D A06B-6041-J121

Orientation circuit D

PCB drawing number A20B-0009-0520

The spindle speed range is as listed below.

	Spindle speed range
High	4000 – 8000 rpm
Medium	1000 – 2000 rpm
Low	250 – 667 rpm

2.3.1 Setting and function of jumper terminal (SH)

See 2.2.1

2.3.2 LED indicators

LED No.	Meaning	Color	Contents
LED1	ORIENTATION	Green	Lights during execution of an orientation command.
LED2H	GEAR/CLUTCH	Green	Lights when the gear/clutch is shifted to high position.
LED2M			Lights when the gear/clutch is shifted to middle position.
LED2L			Lights when the gear/clutch is shifted to the low position.
LED3	MS PEAK LEVEL	Green	Lights when the peak value of the MS signal sent from the magnetic sensor is out of the range of $\pm 10V$.
LED4	SLOWDOWN PERIOD	Green	Lights during low turning speed and goes out when the magnetizing element reaches the sensor.
LED5	IN-POSITION FINE	Green	Lights when orientation has been completed and the spindle is within $\pm 0.1^\circ$ of the adjustment position.
LED6	IN-POSITION	Green	Lights when orientation has been completed and the spindle is within $\pm 1^\circ$ of the adjustment position. When it lights while not in TEST mode, the orientation completion signal is transmitted.
LED7	TEST MODE	Red	Lights when terminals 01 and 02 of SH01 are shorted.

2.3.3 Adjustments


The following adjustments should be performed in TEST mode after turning on the power.

Item	Variable resistor	Adjustment item	Condition	Adjustment procedure
1	RV1	TSA OFFSET Tachogenerator offset	The spindle should be stopped.	Voltage across check terminals CH15 (TSA2) and 16 (0V) should be within 0 ± 1.0 mV.
2	RV2	MS PEAK LEVEL Amplitude adjustment of MS signal	SW1 should be kept pressed.	Adjust the position until LED3 begins to light.
3	RV3	SLOWDOWN REFERENCE Setting of the slowdown level	Measure the distance from the center of the spindle to the sensor head	See NOTE 1.
4	RV4	AMS PEAK LEVEL Amplitude value of AMS signal		
5	RV5	SLOWDOWN TIME Adjusting slowdown time	Shift the gear to the HIGH position and LED2H goes on. Turn SW1 on and off repeatedly.	Just before stopping, LED4 should immediately light up clearly (about 0.2 sec.)
6	RV6	GAIN [HIGH] Position loop gain		Turn clockwise to increase the gain being careful not to overshoot when stopping.
7	RV7	IN-POSITION [H] Adjusting the spindle stop position		Adjust so that LED5 lights while LED6 is on. LED5 may flicker.
8	RV8	SLOWDOWN TIME [LOW] Adjustment of slowdown time	Shift the gear to the LOW position and LED2L goes on. Turn SW1 on and off repeatedly.	Same as item 5 above.
9	RV9	GAIN [LOW] Position loop gain		Same as item 6 above.
10	RV10	IN-POSITION [LOW] Adjusting the spindle stop position		Same as item 7 above.
11	RV12	SLOWDOWN TIME [MEDIUM] Adjusting slowdown time	Shift the gear to the MEDIUM position and LED2M goes on. Turn SW1 on and off repeatedly.	Same as item 5 above.
12	RV13	GAIN [MEDIUM] Position loop gain.		Same as item 6 above.
13	RV13	IN-POSITION [MEDIUM] Adjusting the spindle stop position		Same as item 7 above.
14	RV11	POSITION SHIFT Shifting of spindle stop position	The stop position can be finely adjusted within a range of $\pm 1^\circ$ of the spindle angle.	Match the key position of the ATC arm to the groove position of the spindle.


After adjustment, release test mode making sure that LED7 (Red) is off.


(NOTE 1) Adjust RV3 and RV4 based on the distance (Hmm) from the center of the spindle to the sensor as listed below.

H (mm)	50	60	70	80	90	100	110	120
Position RV3, 4	9.5	6.5	4.5	3.0	2.2	1.5	1.0	0.5



Scale





Location of check terminals and potentiometers.

3. ADJUSTMENT OF POSITION CODER SYSTEM SPINDLE ORIENTATION

3.1 Printed circuit board

Spindle control circuit A20B-0009-0530 ~ 0534

Position coder method spindle orientation control circuit


- | | |
|------------------------------------|----------------|
| (1) Stop position internal setting | A20B-0008-0240 |
| (2) Stop position external setting | A20B-0008-0241 |

3.2 Display

Light emitting diode

- | | | |
|-------------------------|-------|---|
| LED1 ORIENTATION | | Lights when orientation command (ORCM1, 2 ON) is issued. |
| LED2 LOW | | Lights when the contact of clutch change signal *CTH is closed. Lighting indicates that clutch LOW is selected. |
| LED3 IN-POSITION OUT | | Lights when orientation completion signal ORAR 1-2 is issued. |
| LED4 IN-POSITION ADJUST | | Lights when spindle enters within one pulse of orientation position. |
- Stop position can be the same at HIGH and LOW by adjusting POT RV3/RV5 for OFFSET adjustment so that this LED lights at gear HIGH/LOW.

3.3 Setting



- (1) +5V - 5H When the power of +5V for position coder is supplied from spindle amplifier, connect
0G - 0V between +5V and 5H and between 0G and 0V. When the power of +5V is supplied from
NC, open between +5V and 5H and between 0G and 0V.

- (2) Setting of SW5 and SW4

Position coder	Type	SW4	SW5
Balanced type	Type A	Right	Right
Unbalanced type	Type B	Left	Left

- (3) Setting of SH01 and Si02

Follow the next table.

Table 1 Setting of SH01, SH02

O: Connected X: Open

No.	Contents		SH01								SH02								Remarks	
			1	2	3	4	5	6	7	8	1	2	3	4	5	6	7	8		
			1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1		
			16	15	14	13	12	11	10	9	16	15	14	13	12	11	10	9		
1	Initial orientation direction immediately after turning on power	CCW	O	X															(Standard)	
		CW	X	O																
2	Orientation direction after initial orientation	CCW only			X	O													(Standard)	
		CW only			X	X														
		Spindle rotational direction			O	X														(Standard)
3	Orientation speed which is set by position gain	1					X	X												
		2/3					O	X												
		1/3					X	O												
4	Rotational direction of spindle and position coder	Same direction							O	X									Different from machine tool to machine tool. Incorrect setting will cause hunting.	
		Reverse direction							X	O										
5 (Note)	In-position width to issue orientation completion signal (ORAR 1, 2)	±2 pulses										O	O	O	O	O	O		±16 pulses correspond to ±1.3°	
		±4 pulses											O	O	O	O	O			
		±8 pulses												O	O	O	O			
		±16 pulses													O	O	O			
		±32 pulses														O	O			
		±64 pulses															O			
6	Setting due to position coder hysteresis	No pulse															X	X	(Standard)	
		+1 pulse																O	X	
		-1 pulse																X	O	

(Note) The condition (c) of issue of orientation completion signal
 c = (Spindle is within the in-position width) and (Velocity zero signal is ON) and (ORCM is ON)


(4) Setting of stop position SW1, 2, 3

Switch	Contents
SW1 (16 positions)	1 position is $4096/16 = 256$ pulses, equivalent to 22.5° .
SW2 (16 positions)	1 position is $256/16 = 16$ pulses, equivalent to 1.4° .
SW3 (16 positions)	1 position is $16/16 = 1$ pulse, equivalent to 0.088° .

An arbitrary position in a rotation can be positioned by the unit of $0.088^\circ = 1/4096 \times 360^\circ$ by setting in the order of SW1, 2 and 3.

3.4 Adjustment


No.		Variable resistor	Measuring point	Standard Adjustment	Note
1	Velocity feedback offset	RV1	TSA2 CH14	5 scale	The voltage at TSA2 should be ± 1 mV.
2	Position gain at gear High	RV2	Do not let spindle overshoot	3~4 scale	
3	Offset at gear High	RV3	Let LED4 ADJUST light	About 5 scale	Gleaming of the LED is sufficient.
4	Position gain at gear Low	RV4	Do not let spindle overshoot	3~6 scale	
5	Offset at gear Low	RV5	Let LED4 ADJUST light	About 5 scale	



Scale of potentiometer

Appendix II-1 Connection diagram


1.1 Interface (For position coder)




(Note 1) Signal cable K8 is used with the orientation B circuit.

(Note 2) Cable J4 is used when the large position coder or the synchronous * feed position coder for the machining center is used concurrently.

1.1.1 Connection when synchronous feed position coder is concurrently used for lathes and machining centers.




1.1.2 Connection for machining center spindle orientation only




(Note) The cable between the servo unit and the position coder must not exceed 20 meters.

1.1.3 Stop position external setting connection



1.2.1 Magnetic sensor connection



The cable between the servo unit and the magnetic sensor amplifier must not exceed 20 meters.